



VAV WITH REHEAT WORKORDER

Unit Tag: VAVRH-1

Equipment Type
Manufacturer
Model No.
Serial No

Building
Floor
Room name

VAV with HW reheat
XXX
VAVRH
111102870

Special procedure space
First floor
Special procedure room

1998

Year installed



McKew is a senior project engineer with InterPro Solutions. Reach her at amckew@interprosoft.com.

	amckew@interprosoft.com.				
Equipment Information			Description	Item quantity	Actual quantity
Boilers			1		
Special Instructions			Yes	No	N/A
1	Make sure you have special tools.				V
2	Follow lock out/tag out and safety procedures.				V
3 Attach manufacturer's maintenance checklist.					V
4					
5	5				
6					
Task # Monthly		Quarterly	Semi- Annually	Annually	
10	Warning: To prevent personal injury, follow lock out/tag out and safety procedures identified in the manufacturer's manual.			V	V
20	Check with operating personnel for deficiencies.			V	V
30	Open and close VAV control box access.			V	V
40	Verify that the pneumatic tubing/electrical connections are in place and tight.			V	V
50	Tighten arm on motor output shaft.			V	V
60	Cycle actuator while watching for proper operation, verify that blades fully open and close.			V	V
70	Lubricate actuator linkage and damper blade pivot points.			V	V
80	Clean area around unit.			V	V
90	Complete the workorder and report deficiencies.			V	V
Tec	hnician's Comments				
1	Inspect insulation for damage and repair as needed.				
2					
3					